

Pipe Support Installation

Raise pipe from support and prepare the surface.



Thoroughly mix the two component filler and adhesive.



Apply filler material to defect area and adhesive to pipe surface.



Pipe Support Installation

Snap on first layer and apply adhesive.



Snap on second layer.



Tighten and leave to cure.



Completed repair/support.



Complete installation can be completed within 10 – 15 minutes.