

Snap Wrap Installation

Thoroughly mix the two component filler and adhesive.



Apply filler material to defect area and adhesive to pipe surface.



Snap Wrap Installation

Snap on first layer and apply adhesive.



Snap on each layer. Keep applying adhesive.



On completion of eighth layer, apply Jubilee clips.



Tighten and leave to cure.



Complete installation can be completed within 15 – 25 minutes.